

Analytic thermoelectric couple modeling: variable material properties and transient operation

Jon Mackey

Mechanical Engineering,
University of Akron

Alp Sehirlioglu

Materials Science and Engineering,
Case Western Reserve University

Fred Dynys

NASA Glenn Research Center

NASA Cooperative Agreement: NNX08AB43A

NASA/USRA Contract: 04555-004

The
University
of Akron



CASE WESTERN RESERVE
UNIVERSITY EST. 1826

think beyond the possible™



Introduction Variable Properties Transient

Thermoelectricity


- Study of the coupled transport of electrical and thermal energy.
- Solid-state phenomenon requires no moving parts or working fluids, and generates no noise, torque, or vibrations.
 - As a result thermoelectric devices are extremely reliable.
- Power Generation
 - Spacecraft, automotive, aerospace, gas pipelines, well sites, and offshore platforms.
- Refrigeration
 - On chip cooling, electronics, and automotive.
- **High reliability, low conversion efficiency.**

Spacecraft Power

- Radioisotope thermoelectric generators (RTG) have powered 45 spacecraft.
 - Voyager (1977), Ulysses (1990), Cassini (1997), New Horizons (2006), and Curiosity (2011).


Lange et al. Energy Conversion and Management **49** (2008) 391-401.

GPHS-RTG (Galileo/Ulysses)



Bennett et al. AIP Proceedings **969** (2008) 663-671.

New Horizons




- Stud
- ele
- So
- no
- and
- vib

- As a result thermoelectric devices are extremely reliable.

Voyager



efficiency.




Curiosity

- R
- (R

ors

401.



Galileo

Bennett et al. Air Proceedings 363 (2006) 663-671.

Introduction Variable Properties Transient

Thermoelectric

- Study of the coupling between electrical and thermal properties.
- Solid-state phenomenon with no moving parts and generates no mechanical vibrations.



Lange et al. Energy Conversion and Management **49** (2008) 391-401.

BMW

- Power Generation
- Spacecraft, aerospace sites, and
- Refrigeration
 - On chip cooling
 - automotive
- **High reliability and efficiency.**




Bennett et al. AIP Proceedings **969** (2008) 663-671.


Power

Electric generators in spacecraft. (1990), Horizons (2011).

Analysis



Thermocouple



© Nature Publishing Group
Jeff Snyder, Caltech


$$\eta = \frac{P_{out}}{Q_{in}}$$

Irreversible Thermodynamics

- 1931 Lars Onsager discussed coupled irreversible processes to unify thermoelectric phenomena into a single study.
- Study results in two transport laws for a thermoelectric conductor.


Ohm's Law-
$$eJ_N = -\sigma \frac{d\phi}{dx} - S\sigma \frac{dT}{dx},$$

Fourier's Law-
$$q'' = STeJ_N - k \frac{dT}{dx}.$$



Introduction Variable Properties Transient

Classic Model



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = -S_{A,B} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$

Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$

$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$


$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Classic Model

Four Assumptions



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = -S_{A,B} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$

Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$


$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Classic Model



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = -S_{A,B} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$

Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$


$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Classic Model



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = -S_{A,B} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$

Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$


$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Classic Model



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \boxed{\frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = -S_{A,B} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$

Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$


$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Classic Model



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = -S_{A,B} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$

Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$


$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Classic Model



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = \boxed{-S_{A,B} \frac{dT_{A,B}}{dx}} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$

Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$


$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Classic Model



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = -S_{A,B} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$

Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$


$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Classic Model



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = -S_{A,B} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$

Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$


$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Classic Model



Thermal-

$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

Electrical-

$$\frac{d\phi_{A,B}}{dx} = -S_{A,B} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-

$$\phi_B(L_B) - \phi_A(L_A) = IR$$

Classic Parameters

Geometric-

$$X = \frac{A_B L_A}{A_A L_B}$$

Load-

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

Materials-

$$Z(X) = \frac{(S_B - S_A)^2}{\left(\frac{1}{\sigma_A} + \frac{1}{\sigma_B X} \right) (k_A + k_B X)}$$


Classic Solution

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$

$$X_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$Y_{opt} = \sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$Z(X_{opt}) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$



Mackey et al. Applied Energy **134** (2014) 374-381.

Parameters

$$X = \frac{A_B L_A}{A_A L_B}$$

R

Solution Parameters

$$X = \frac{A_B L_A}{A_A L_B}$$

$$Y = \frac{R}{\frac{L_B}{\sigma_B A_B} + \frac{L_A}{\sigma_A A_A}}$$

$$\eta_{opt} = \frac{\eta_c Y_{opt}}{\frac{(1 + Y_{opt})^2}{T_h Z(X_{opt})} + (1 + Y_{opt}) - \frac{1}{2} \eta_c}$$


$$\eta_{opt} = \sqrt{\frac{k_A \sigma_A}{k_B \sigma_B}}$$

$$\sqrt{1 + Z(X_{opt}) T_{avg}}$$

$$) = \frac{(S_B - S_A)^2}{\left(\sqrt{\frac{k_A}{\sigma_A}} + \sqrt{\frac{k_B}{\sigma_B}} \right)^2}$$

Introduction Variable Properties Transient

Variable Properties Model



Material Properties by Asymptotic Expansion-

$$\frac{1}{\sigma(T)} = \rho(T) = \tilde{\rho} \frac{\rho(T)}{\tilde{\rho}} = \tilde{\rho}(\rho_0 + \epsilon \rho_1 \Delta T \hat{T})$$

$$S(T) = \tilde{S} \frac{S(T)}{\tilde{S}} = \tilde{S}(S_0 + \epsilon S_1 \Delta T \hat{T})$$

$$k(T) = \tilde{k} \frac{k(T)}{\tilde{k}} = \tilde{k}(k_0 + \epsilon k_1 \Delta T \hat{T})$$

Asymptotic Expansion


$$\hat{T} = \frac{T}{\Delta T} \quad \hat{\phi} = \frac{\phi}{\Delta S \Delta T} \quad \hat{I} = \frac{IR}{\Delta S \Delta T}$$

$$\hat{T} = T_0 + \epsilon T_1$$

$$\hat{\phi} = \phi_0 + \epsilon \phi_1$$


Variable Seebeck

Max Conversion Efficiency [%], Fixed Average Seebeck



Introduction Variable Properties Transient

Variable Properties Model



Material Properties by Asymptotic Expansion-

$$\frac{1}{\sigma(T)} = \rho(T) = \tilde{\rho} \frac{\rho(T)}{\tilde{\rho}} = \tilde{\rho}(\rho_0 + \epsilon \rho_1 \Delta T \hat{T})$$

$$S(T) = \tilde{S} \frac{S(T)}{\tilde{S}} = \tilde{S}(S_0 + \epsilon S_1 \Delta T \hat{T})$$

$$k(T) = \tilde{k} \frac{k(T)}{\tilde{k}} = \tilde{k}(k_0 + \epsilon k_1 \Delta T \hat{T})$$

Asymptotic Expansion


$$\hat{T} = \frac{T}{\Delta T} \quad \hat{\phi} = \frac{\phi}{\Delta S \Delta T} \quad \hat{I} = \frac{IR}{\Delta S \Delta T}$$

$$\hat{T} = T_0 + \epsilon T_1$$


$$\hat{\phi} = \phi_0 + \epsilon \phi_1$$

Variable Seebeck

Max Conversion Efficiency [%], Fixed Average Seebeck



Variable Properties



Material Properties

$$\rho(T) = \tilde{\rho} \frac{\rho(T)}{\tilde{\rho}} = \tilde{\rho}(\rho_0 + \epsilon \rho_1 \Delta T \hat{T})$$

$$S(T) = \tilde{S} \frac{S(T)}{\tilde{S}} = \tilde{S}(S_0 + \epsilon S_1 \Delta T \hat{T})$$


$$k(T) = \tilde{k} \frac{k(T)}{\tilde{k}} = \tilde{k}(k_0 + \epsilon k_1 \Delta T \hat{T})$$

$$\sigma(T) = \rho(T) = \rho \frac{\rho(T)}{\tilde{\rho}} = \rho(\rho_0 + \epsilon \rho_1 \Delta T \hat{T})$$

$$S(T) = \tilde{S} \frac{S(T)}{\tilde{S}} = \tilde{S}(S_0 + \epsilon S_1 \Delta T \hat{T})$$

$$k(T) = \tilde{k} \frac{k(T)}{\tilde{k}} = \tilde{k}(k_0 + \epsilon k_1 \Delta T \hat{T})$$

Asymptotic Expansion Method







$$\frac{d}{dx} \left[-k_{A,B} \frac{dT_{A,B}}{dx} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{dT_{A,B}}{dx} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = 0$$

- Leading order temperature solution
- First order temperature correction
- Combined temperature solution

Asymptotic Expansion Method


$$= \frac{IR}{\Delta S \Delta T}$$











Material






Conversion-



Variable Seebeck








Variable Resistivity

Max Conversion Efficiency [%], Fixed Average Elec. Resistivity




Introduction Variable Properties Transient


Variable Property Model Summary

Material Property	Temperature Dependence	Conversion Efficiency	Sensitivity (K)
Thermal Conductivity	↑	↑	0.60
Absolute Seebeck Coefficient	↑	↑	0.25
Electrical Resistivity	↑	↓	0.08


$$Sensitivity = \frac{\Delta\eta}{\Delta(S_1)}$$



Conversion Efficiency 6.69%




Conversion Efficiency 6.30%



Conversion Efficiency 6.10%

Introduction Variable Properties Transient

Transient Model



Thermal-
$$\frac{\partial}{\partial x} \left[-k_{A,B} \frac{\partial T_{A,B}}{\partial x} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{\partial T_{A,B}}{\partial x} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = \rho_{A,B} c_{pA,B} \frac{\partial T_{A,B}}{\partial t}$$

Electrical-
$$\frac{\partial \phi_{A,B}}{\partial x} = -S_{A,B} \frac{\partial T_{A,B}}{\partial x} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-
$$\phi_B(L_B) - \phi_A(L_A) = IR + H \frac{dI}{dt}$$

Green's Function Solution

Diagram illustrating the Green's function solution for a boundary value problem. The diagram shows a beam of length L with a distributed load $f(x)$ and a point load $\delta(x - \xi)$. The displacement $u(x)$ is shown. The Green's function $G(x, \xi)$ is shown as a triangular pulse. The equations are:

$$\mathcal{L}u(x) = f(x)$$

$$\mathcal{L}^*G(x, \xi) = \delta(x - \xi)$$

$$u(x) = \int G(x, \xi) f(\xi) d\xi$$

Transient Parameters

Thermal diffusivity factor-


$$\Gamma_{A,B} = \frac{\alpha_{avg} L_{A,B}^2}{\alpha_{A,B} L_{avg}^2}$$

Inductance factor-

$$\beta = \frac{H \alpha_{avg}}{R L_{avg}^2}$$

Introduction Variable Properties Transient

Transient Model



Thermal-
$$\frac{\partial}{\partial x} \left[-k_{A,B} \frac{\partial T_{A,B}}{\partial x} \right] + \frac{I_{A,B} \tau_{A,B}}{A_{A,B}} \frac{\partial T_{A,B}}{\partial x} - \frac{I_{A,B}^2}{A_{A,B}^2 \sigma_{A,B}} = \rho_{A,B} c_{p_{A,B}} \frac{\partial T_{A,B}}{\partial t}$$

Electrical-
$$\frac{\partial \varphi_{A,B}}{\partial x} = -S_{A,B} \frac{\partial T_{A,B}}{\partial x} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

System-
$$\varphi_B(L_B) - \varphi_A(L_A) = IR + H \frac{dI}{dt}$$

Green's Function Solution

$\mathcal{L}u(x) = f(x)$

$\mathcal{L}^*G(x, \xi) = \delta(x - \xi)$

$$u(x) = \int G(x, \xi) f(\xi) d\xi$$

Transient Parameters

Thermal diffusivity factor-



$$\Gamma_{A,B} = \frac{\alpha_{avg} L_{A,B}^2}{\alpha_{A,B} L_{avg}^2}$$

Inductance factor-

$$\beta = \frac{H \alpha_{avg}}{R L_{avg}^2}$$

Introduction Variable Properties Transient

Transient Model



$T_H(t), \varphi_H$

L_A

$T_C(t), \varphi_{C,A,B}$

Thermal- $\frac{\partial}{\partial x} \left[-k \frac{\partial T}{\partial x} \right]$


Electrical-

System-

$$\frac{\partial \varphi_{A,B}}{\partial x} = -S_{A,B} \frac{\partial T_{A,B}}{\partial x} - \frac{I_{A,B}}{A_{A,B} \sigma_{A,B}}$$

$$\varphi_B(L_B) - \varphi_A(L_A) = IR + H \frac{dI}{dt}$$

Green's Function Solution



$$\mathcal{L}u(x) = f(x)$$

$(x - \xi)$

Thermal Green's Function

Eigenfunction expansion-

$$G_{a,b}(\xi, \tau; x, t) = \frac{-2}{\Gamma_{a,b}} H(t - \tau) \sum_{n=0}^{\infty} e^{\frac{\lambda_n^2}{\Gamma_{a,b}}(\tau - t)} \cos(\lambda_n x) \cos(\lambda_n \xi),$$

Eigenvalue-

$$\lambda_n = \frac{(2n + 1)\pi}{2},$$

Temperature-

$$\begin{aligned} \hat{T}_{a,b}(x, t) = & -\Gamma_{a,b} \int_0^1 G_{a,b}(\xi, 0; x, t) T_i d\xi + \int_0^t G_{\xi,a,b}(1, \tau; x, t) T_c d\tau \\ & - \int_0^t G_{a,b}(0, \tau; x, t) (A \sin(\omega \tau) + B) d\tau - \int_0^t \int_0^1 G_{a,b}(\xi, \tau; x, t) \gamma I^2(\tau) d\xi d\tau. \end{aligned}$$



factor-

Inductance factor-

$$\alpha_{A,B} = \frac{H_{avg} L_{A,B}^2}{\alpha_{A,B} L_{avg}^2}$$

$$\beta = \frac{H \alpha_{avg}}{R L_{avg}^2}$$

Periodic On/Off Operation



Design Guideline

$$\frac{L_A}{L_B} = \frac{\sqrt{2a} + 1}{2a - 1}$$

$$a = 1 + \frac{\alpha_B}{\alpha_A}$$

$$\mathcal{L}u(x) = f(x)$$

$$u(x) = \int G(x, \xi) f(\xi) d\xi$$

Transient Parameters



Thermal diffusivity factor-

$$\Gamma_{A,B} = \frac{\alpha_{avg} L_{A,B}^2}{\alpha_{A,B} L_{avg}^2}$$


Inductance factor-

$$\beta = \frac{H \alpha_{avg}}{R L_{avg}^2}$$

Power Output Amplitude



Sinusoidal Operation



Transient Parameters

Thermal diffusivity factor-

$$\frac{L}{\sqrt{\alpha \tau}} = \frac{RC}{\sqrt{\tau}}$$

Inductance factor-

$$\frac{L}{4} = \frac{RC}{\tau}$$

Conclusion

- Asymptotic expansions are an effective means of understanding thermocouple behavior.
- Conversion efficiency is most sensitive to thermal conductivity temperature dependence.
- Thermal diffusivity factor
 - Governs transient operation of a thermocouple, with an ideal value of unity.
- Inductance factor
 - Governs the balance between thermal and electrical inductance.

Acknowledgements

Tom Sabo, Ray Babuder, Ben Kowalski
NASA Glenn Research Center/
Case Western Reserve University

Dr. Sabah Bux, Dr. Jean-Pierre Fleurial
JPL

NASA Cooperative Agreement:
NNX08AB43A

NASA/USRA Contract:
04555-004

